



Precision Metals Ltd.
8081 132nd Street
Surrey, BC V3W 4N5

Ph: (604) 594-6001
E: sales@precisionmetals.ca

ALUMINUM PLUMBING FLASHING

INSTALLATION INSTRUCTIONS

1. Remove all debris from roof deck around plumbing pipe, to allow flashing stack to sit flat on roof deck.
2. Slide flashing stack over pipe, making sure the flashing stack's flange sits flat onto the roof deck.
3. Fasten flange onto roof deck using a minimum of 4 evenly spaced fastening screws placed 1" from edge of flange, screwed into the solid roof substrate.
4. Install roofing membrane over the flashing stack flange as per roofing product manufacturer's installation procedures for flashing details.
5. Install appropriate cap onto top of flashing stack.
6. Flashing stack installation must adhere to regulations set by regional governing bodies and manufactures requirements.

YOUR METAL SPECIALISTS SINCE 1975