



Precision Metals Ltd.  
8081 132nd Street  
Surrey, BC V3W 4N5

Ph: (604) 594-6001  
E: [sales@precisionmetals.ca](mailto:sales@precisionmetals.ca)

## **INTAKE PANEL VENT**

### **INSTALLATION INSTRUCTIONS**

#### *SPLIT PANEL INSTRUCTIONS – SNAP LOCK & STANDING SEAM*

1. Locate where you want the intake vent to be up from the eave and be sure it will be centered in panel
2. Cut a 6" x 6" hole in the roof deck at vent location
3. Remove any debris or materials that will prevent the vent and panel from laying flat on the roof deck
4. Cut a panel 16" longer than the measurement from eave to top of hole. Cut a 6" x 6" hole in the panel to line up with hole in roof deck. Fasten/secure panel as designed.
5. Install bead of accepted sealant to underside of vent flange.
6. Place vent, centered over hole so interior damper flange lines up with bottom of hole.
7. Secure vent to roof deck using 2 broad head fasteners, at top of vent flange 1" in from corners.
8. Install top panel (with U cut and safety edges) over the Intake vent. Installation as per ASM guidelines.
9. Vent installation must adhere to regulations set by regional governing bodies and manufactures requirements.

*YOUR METAL SPECIALISTS SINCE 1975*